

Widerstandstabelle der TVS Seeshaupt GmbH:

für Temperaturfühler ÖKOTemp3000 und ÖKOTemp4000

Temperatur in °C	Temperatur in °F	Widerstand TVS Sensor in KOhm
-50	-58	203,98000
-45	-49	150,72000
-40	-40	112,54000
-35	-31	84,88400
-30	-22	64,63200
-25	-13	49,65800
-20	-4	38,48100
-15	5	30,06500
-10	14	23,67200
-5	23	18,77700
0	32	15,00000
5	41	12,06400
10	50	9,76540
15	59	7,95370
20	68	6,51650
25	77	5,36940
30	86	4,44820
35	95	3,70440
40	104	3,10040
45	113	2,60730
50	122	2,20290
55	131	1,86940
60	140	1,59320
65	149	1,36340
70	158	1,17140
75	167	1,01030
80	176	0,87459
85	185	0,75978
90	194	0,66232
95	203	0,57927
100	212	0,50826
105	221	0,44734
110	230	0,39490
115	239	0,34962
120	248	0,31040
125	257	0,27633
130	266	0,24665
135	275	0,22071

Formel für °C in °F:

$$(xxx^{\circ}\text{C} / 0,555) + 32 = ^{\circ}\text{F}$$



TVS Seeshaupt GmbH
 Thermo-Verbund-Systeme
 Am Grundwassersee 10
 82402 Seeshaupt

Tel: 08801-912-605
FAX: 08801-912-606
eMail: zentrale@tvsgmbh.de
Internet: www.tvsgmbh.de